

Insul-Bright[®]

Needlepunched Insulated Lining

The shiny side of your Insul~Bright should face the hot or cold item allowing it to reflect the energy back to its source. The polyester protects your hands, while the cotton batting absorbs condensation. No pre-wash is necessary. Machine wash warm & tumble dry finished oven mitt and pot holder.

Oven Mitt Instructions

- 1) Cut two 9" x 12" pieces from each fabric - cover fabric, Insul~Bright, Warm & Natural batting & the lining fabric.
- 2) Trace enlarged oven mitt pattern on right side of one 9" x 12" piece of cover fabric. Trace a reversed mitt on the right side of the other piece of cover fabric.
- 3) Layer and baste oven mitt fabrics together in this order: cover fabric, Insul~Bright, Warm & Natural cotton batting, lining fabric. Zig-zag stitch through all fabrics around the cuff edge of the oven mitt. Trim away excess fabric from cuff edge. Make a reversed set.
- 4) Bind entire cuff edge with bias binding. If desired, add a hanging loop by stitching the ends of a 4" length of ribbon under the binding.
- 5) Lay the sets of fabric together with lining fabrics facing out. Zig-zag stitch around all edges EXCEPT the cuff edge. Trim away excess fabric from zig-zagged edge. Turn right side out.

**Enlarge by
60%**

*Make a matching pot holder by cutting two 6" squares of cover fabric & sandwich a layer of Insul~Bright between layers of Warm & Natural. Add 1/4" binding around.

Insul~Bright Recommendations

Use with at least one layer of cotton batting, such as Warm & Natural or Warm & White, to absorb condensation.

Made In USA • Satisfaction Guaranteed!
Not Intended for Microwave Use



(800) 234-9276
www.warmcompany.com

